
Driscoll/Dubin/O'Neil, UCSD


Cyclotron Modes in Multispecies Ion Plasmas

Plasmas exhibit a variety of cyclotron modes, which are used in a broad range of devices to manipulate and diagnose charged particles. However, plasma electric fields shift the mode frequencies away from the "bare" cyclotron frequencies $2\pi F_c^{(s)} = q_s B/M_s$ for each species s. Theory analysis (Dubin 2013) for un-neutralized ion plasmas gives precise predictions of these shifts for the "regular" $m_{\theta} = 1$ (center-of-mass) mode, for the unusual $m_{\theta} = 2$ mode, and for the novel $m_{\theta} = 0$ mode, which has no radial electric field (cartoons shown). For a species of fraction δ_s , the frequency shift is given by

$$f_{m_{\theta}}^{(s)} - F_{c}^{(s)} = \left[\left(m_{\theta} - 2 \right) + \delta_{s} \left(1 - R \right) \right] f_{E},$$

where f_E is the ExB drift rotation frequency, and R represents a small image charge correction from the conducting wall.





A new laser-thermal cyclotron spectroscopy technique (Affolter 2014) gives the first quantitative measurements of these shifts. The figure shows frequency measurements of the $m_{\theta} = 0$, 1, and 2 modes for ²⁴Mg⁺. A theory fit to the data shown gives $F_c^{(24)}$ to an accuracy of 2 parts in 10⁴, and determines the species fraction and in-plasma electric field to high accuracy. These new results are relevant to "space charge" and "amplitude" calibrations for cyclotron mass spectroscopy devices widely used in molecular chemistry and biology.

M. Affolter et al., J. Am. Soc. Mass Spectrom, 26, 330 (2015).
M. Affolter et al., Phys. Plasmas, 22, 055701 (2015)
D.H.E. Dubin, Phys. Plasmas, 20, 04120 (2013)